

## Step 1

Place panels with open hole sockets on the floor. Insert 36" legs in each panel as shown. (Make sure legs are pushed all the way down).

## Structural Plastics Corporation

- 3401 Chief Drive - Holly, Michigan 48442-9333 - Phone (810) 953-9400 - Fax (810) 953-9440 1-800-523-6899 Easy\_Cube\_inst36/0701

Place panels with closed hole

sockets on legs as shown.