

Step 2

Lower Level

Turn over and slide (3) 24" legs through sockets A,B and C as shown. (Push legs all the way down).



Step 3 Top Level Place 2.5' Top Panel on 24" legs using sockets A,B and C. (Make sure panel is pushed all the way down).

