

Lay (1) bottom solid panel on the floor. Next, insert (4) 30" legs into open hole sockets and push down until leg stops at bottom of socket as shown.







Step 3 **Top Tool Panel**

Next, position the top tool panel (closed hole sockets) on the 30" legs and push it all the way down until the legs are completely inserted in the sockets. Make sure holes in top tool panel match bottom tool panel as shown.

Casters Lay entire unit down and insert casters as shown.



Structural Plastics - 3401 Chief Drive - Holly, Michigan 48442-9333 - Phone (810) 953-9400 - Fax (810) 953-9440 1-800-523-6899

btcs363724/0812

Copyright © 2012 All rights reserved.