

ASSEMBLY INSTRUCTIONS SC667203W

Oil All Sockets Before Assembly

Components: Plant Hanger Tops: 3 Plant Hanger Collars: 9 Plant Hanger Poles: 3 Bolts: 18 Wingnuts: 18



Next, place **63"plant hanger poles** into small groove in plant hanger top . Place **plant hanger collars** over poles and fasten down with bolts and wingnuts.



PATENT PENDING

- 3401 Chief Drive - Holly, Michigan 48442-9333 - Phone (810) 953-9400 - Fax (810) 953-9440 1-800-523-6899 sc667203w_inst/0307 Copyright © 2007 All rights reserved.

Page 2

ASSEMBLY INSTRUCTIONS SC667203W

Oil All Sockets Before Assembly

Accessories: (3) - Mobile Bars



Step 8 **Mobile Bar**

Position fixture on its back side and insert the stems of the mobile bar inside the sockets as shown.

Brakes go to the front of the fixture.



PATENT PENDING

Structural Plastics Corporation - 3401 Chief Drive - Holly, Michigan 48442-9333 - Phone (810) 953-9400 - Fax (810) 953-9440 1-800-523-6899 sc667203w_inst/0407 Copyright © 2007 All rights reserved.

Page 3