

Step 1

Lay floor panels **(open hole sockets)** in position and place legs as shown. (Make sure legs go through to ground).

Step 2 and Step 3

Position the (2) 1st level and (2) 2nd level panels (closed hole sockets) overhanging outside edges as shown. Push down until leg rests on top of socket.

Step 4

Place the remaining **12**" **legs** in the outside sockets of the 3rd level panel. Next position panel on **36**" **legs** using inside row of sockets as shown. Push down until leg rests on top of socket.

Structural Plastics

- 3401 Chief Drive - Holly, Michigan 48442-9333 - Phone (810) 953-9400 - Fax (810) 953-9440 **1-800-523-6899** sm36-66-963605p_inst/1098